

TAYLOR RACE ENGINEERING
2010 AVENUE G UNIT 914
PLANO, TX 75074
PHONE 972-422-0567
FAX 972-422-8677

SNUBBER PLUNGER
SETUP FOR FSAE AND
OSR TRIPOD PN 02002011

DECEMBER 9, 2001

INSTRUCTIONS:

1. CUT PLASTIC FILLER ROD PN 02003165 TO A LENGTH OF 4.350" LESS THAN THE LENGTH OF THE HALF-SHAFT.
2. PRESS PN 02003162 PIVOT PLUG INTO INBOARD END OF AXLE. DRILL THROUGH FOR 1/16" ROLL PIN AND INSTALL 1/16" X 3/4" ROLL PIN (PN RP11634) TO ATTACH PIVOT PLUG
3. INSERT PLASTIC FILLER IN OUTBOARD END FOLLOWED BY SPRING PN 02003164 AND PLUNGER PN 02003161
4. WHEN INSTALLING AXLE IN TRIPOD HOUSING INSURE THAT PLUNGER DOES NOT COCK IN AXLE HOLE. CHECK FOR FREEDOM OF MOTION

